

# Tobii Eye Tracker 5

## Connect to PC

### Placement

Do not mount the eye tracker on top of your screen. Place the eye tracker at the center of the lower part of the screen bezel. Place your mount at the center of your screen underneath screen bezel.



### Set Up

- Tobii Eye Tracker 5 uses the Tobii Experience app, just plug your tracker in and your PC will download both the drivers and the app itself automatically through Microsoft Store.
- If your device is not compatible with the Tobii Experience app, please install the Tobii Core software.
- Complete calibration through Tobii Experience App
- If there are any issues detecting your eyes, please make sure you're positioned correctly in front of the eye tracker. You need to be placed within 50 - 95 cm in front of the eye tracker and at a proper height for the sensors to detect your eyes.
- Download and install Tobii Game Hub

### Tobii Game Hub

- After installing Tobii Game Hub application, calibrate eye-tracker
- Base settings will work with most games but further configuration options are available in menu.
- Recommended to bind hotkey to reset head tracking under 'Control Features'.
- Tobii Game Hub needs to stay open in the background while gaming
- Only games that are supported on Tobii Gaming Hub can utilize eye tracking. Tobii currently enables 172 games